BT-04D
BT Adaptor for Mobile Radio

Parts Name and Functions

(1) **LED indicator:** Glow in red color to show the current BT status.
(2) **VR2**: Received audio input can be adjusted via VR2 trim pot.
(3) **VR1**: Mic audio can be adjusted via VR1 trim pot
(4) **Antenna Connector(SMA Type):** Fit the supplied antenna to this connector or connect the external cable to obtain maximum performance.
(5) **D-SUB 15 :** refers DB15 connector



(6) **Power ON/OFF Switch:** Push this switch to turn on/off the device

Basic Operation

Push the power on/off switch to turn the device ON or OFF.

Pair Mode

Push the power on/off switch for 6 second to go into pair mode, the LED indicator will flash twice per second.

Initial passkey is 0000,

LED indicators

State	LED Indicators
Pairing	LED blinks
Linking mode	LED solid for 2 seconds
Lost linking	LED solid on

DB15 Connector



Note: Pin 10,11,14,15 used to upgrade firmware

REXON TECHNOLOGY CO.,LTD

Telephone:+886-4-24914141 Fax:+886-4-24912042
Address: 261, Jenhua Rd., Dali Dist, Taichung City 412 Taiwan,
Website: http://www.rexontec.com.tw
E-Mail: rexontec@rexontec.com.tw