# BA-10 Bluetooth Adaptor

## Overview

BA-10 is the wireless PTT for two way radio.
By establish a link between BA-10 and wireless adaptor*, communications are securely transmitted from the radio adapter to the BA-10 without use of wires.

Control & Connections

❶ PTT

❷ Power and LED indicator / Phone button

❸ Jack for earphone and microphone

❹ Micro-USB and Charger

❺ Clothing Clip

❻ Volume Up

❼ Volume Down

ON/OFF

Power switch to power on/off

Power ON/OFF LED and Tone Indicators

| Power	LED Indication (Audio and Standalone PTT Device)	Tone Indication (Audio Device)
On	Blue LED blinks 3 times then off	Power On Tone. Hold for 3 second
Off	Blue LED blinks 3 times then POWER OFF	Power OFF Tone. Hold for 3 seconds
Pairing	Blue LED blinks, every 1 sec.	Pairing mode Tone, Hold for 6 second

Pairing

Press 6 sec to Pairing mode

- First time connection, verify that both the host and the wireless device are in pairing mode

- Press and hold the power button for 6 sec, then into pairing mode, Blue LED blinks every 1 sec and pairing mode Tone.

- Once the devices are paired successfully, a ring indication is played on the audio device. And blue LED illuminate for 2 sec. then blue Led Heartbeat: Long OFF and Short ON

Wireless Link and Pairing Indicators

| State	LED Indication (Audio and Standalone PTT Device)	Tone Indication (Audio Device)
Pairing	Blue LED blinks	Pairing Ready Tone
Paired Successfully	Blue LED Solid for 2 seconds	Pairing Successful Tone
Wireless Link Connected with Host	Blue LedHeartbeat: Long OFF and Short ON	Connected Tone
Wireless Link Disconnected from Host	Blue LED Solid ON	Disconnected Tone every 1 minutes for 10 minutes

REXON

What An Excellent Radio!

Volume adjust

Volume down

Volume up

| Button Push	Tone Indication (Audio Device)
Volume Up	VolumeTone with increased loudness
VolumeDown	Volume Tone Played with decreased loudness

Minimum Volume 1 2 3 4 5 6 Maximum Volume

Charging

Red LED

Micro-USB

Battery Alerts and Charging LED Indicators

State	LED indication	Tone Indication
Low Battery Indication	Red LED Heartbeat	Low Battery Tone every 1 minute, less then 30min minutes battery life
Charging	Red LED illuminated	
100% charged	Red LED off	

Dark mode

Volume down

Volume up

Power on

LED OFF in all condition

• Dark Mode allows the user to turn off the LEDs on the wireless device. Placing the wireless device in Dark Mode:

– The wireless device can be put in Dark Mode during power ON by simultaneously pressing Volume Up and Volume Down buttons.

– A feedback tone is heard to alert the user that the LEDs are turned off.

– Once the device is turned on, it can be toggled IN and OUT of Dark Mode by simultaneously pressing power button, Volume Up and Volume Down for 3 seconds.

Trouble shooting

If at any time the wireless connection cannot be re-established, or the device is operating incorrectly:
1. Power Cycle the device and the two-way radio. The connection should re-establish.
2. If the problem continues; Refer to "Pairing Your Audio Device" on page 8 to repeat the connection process.

REXON TECHNOLOGY CO.,LTD

Telehone:+886-4-24914141   Fax:+886-4-24912042

Address: 261, Jenhua Rd., Dali Dist, Taichung City 412 Taiwan,

Website: http://www.rexontec.com.tw

E-Mail: rexontec@rexontec.com.tw

REXON ®

What An Excellent Radio!